

ISUZU Genuine Parts Catalogue


Genuine Isuzu parts · ezdanparts.com · Al Nakheel Branch: 0503000217

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
ENGINE / TRANSMISSION				
1		**7-55198535-0**	BELT, A/C CMPR	Belt
2		**8-97362926-0**	BELT, COOLING FAN	Belt
3		**8-97910219-0**	BELT: COOLING FAN	Belt
4		**8-97912594-0**	BELT: COOLING FAN	Belt
5		**8-97942728-0**	BELT: A/C CMRP	Belt
6		**8-97985121-0**	BELT, A/C CMPR	Belt
7		**8-98088385-0**	BELT, A/C CMPR	Belt
8		**8-97352889-0**	BUSHING: CONNROD	Bush

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
9		**8-97302291-0**	CLUTCH: COOLING FAN	Clutch
10		**8-98119213-1**	CLUTCH, COOLING FA	Clutch
11		**8-98156299-2**	DISC: CLUTCH	Clutch
12		**8-97941521-0**	DISC: CLUTCH	Clutch Disc
13		**8-97946616-1**	CLUTCH OIL DAMPER ASSEMBLY	Clutch Oil Damper
14		**8-97318799-0**	COVER: CLUTCH PEDAL	Clutch Pedal
15		**8-97941522-0**	PLATE ASM: PRESSURE	Clutch Pressure Plate
16		**8-97943331-0**	PLATE ASM: PRESSURE	Clutch Pressure Plate
17		**8-98283194-0**	PLATE ASM: PRESSURE	Clutch Pressure Plate
18		**8-97942296-0**	CYLINDER: SLAVE,CL	Clutch Save Cylinder

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
19		**8-97946624-2**	CYLINDER: SLAVE,CL	Clutch Save Cylinder
20		**8-97388735-0**	METAL SET: CONNECTING ROD	Connecting Rod
21		**8-97524024-0**	ROD ASM: CONN	Connecting Rod
22		**8-98152983-0**	LEVER: CHANGE	Door Handle
23		**8-97367272-0**	RUBBER ENG FOOT, F	Engine Mounting
24		**8-97367273-0**	RUBBER ENG FOOT, F	Engine Mounting
25		**8-97916330-0**	RUBBER: ENG FOOT, FRT	Engine Mounting
26		**8-97916331-0**	RUBBER: ENG FOOT, FRT	Engine Mounting
27		**8-98075376-2**	MOUNTING ASSEMBLY: ENGINE	Engine Mounting
28		**8-98250592-0**	ENGINE MOUNTING ASSEMBLY	Engine Mounting

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
29		**8-97942974-0**	PISTON(GRADE B)	Engine Piston
30		**8-98028117-0**	PISTON	Engine Piston
31		**8-98132548-1**	PISTON	Engine Piston
32		**8-98132708-1**	PISTON, O/S-0.50	Engine Piston
33		**8-97555602-0**	EVAPORATOR ASM, HE	Evaporator
34		**8-98139376-2**	EVAPORATOR ASM, HE	Evaporator
35		**8-97921857-1**	FAN: COOLING	Fan
36		**8-98162703-0**	FAN COOLING	Fan
37		**8-98189874-0**	GUIDE: FAN	Fan Shroud
38		**8-98189876-0**	FAN SHROUD	Fan Shroud

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
39		**8-97528034-0**	UNIT: FUEL PUMP	Fuel Pump
40		**8-97920514-1**	GASKET: INL MANIF	Gasket
41		**8-97943088-0**	GASKET: OUTLET PIP	Gasket
42		**8-97943955-0**	GASKET: SLEEVE, INJ	Gasket
43		**8-98017270-0**	GASKET: PIPE TO MA	Gasket
44		**8-97947079-0**	GASKET: CAM END	Gasket Cam End
45		**8-97263052-0**	GASKET: EXHAUST PIPE	Gasket Exhaust
46		**8-97945338-0**	GASKET: HD TO COVE	Gasket Head Cover
47		**8-98275338-1**	COVER: FRONT, TRANS C	Gear Case Cover
48		**1884055012**	Grease Besco L3	Grease

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
49		**8-98119278-1**	LEVER: TENSION, TIMING CHAIN GUIDE	Guide Timing Chain
50		**8-98173188-0**	GUIDE, TIMING CHAIN	Guide Timing Chain
51		**8-97940140-1**	HOSE: VAC PUMP	Hose
52		**8-97943682-0**	HOSE RUBBER, POWER	Hose
53		**8-98003995-0**	HOSE WATER, RAD OU	Hose
54		**8-98003996-0**	HOSE, WATER RAD IN	Hose
55		**8-98090629-2**	HOSE: WATER, RAD IN	Hose
56		**8-98278811-0**	HOSE: CONN	Hose
57		**8-98373700-1**	HOUSING: THERMOSTAT LOWER PART	Housing Thermostat
58		**8-98194004-4**	COOLER: CHARGE AIR	Intercooler

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
59		**8-97945853-0**	LEVER: CHANGE	Lever
60		**8-97388502-0**	METAL SET: CRANKSHAFT	Metal Set Crankshaft
61		**8-94156589-0**	OIL SEAL: RR COVER, GEN	Oil Seal
62		**8-97216792-0**	SEAL: OIL, RR HUB, O	Oil Seal
63		**8-97943951-0**	SEAL: OIL, CRANK SHAFT, F	Oil Seal
64		**8-97315231-2**	PIPE ASM: LEAK OFF	Pipe Leak Off
65		**8-98150333-0**	PIN, PISTON	Piston Pin
66		**8-97942518-0**	RING SET: PISTON, S	Piston Ring Set
67		**8-98171041-0**	RING SET, PISTON	Piston Ring Set
68		**8-97912530-0**	PLUG: DRAIN, OIL	Plug Drain Oil

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
69		**8-98137277-5**	RADIATOR ASM	Radiator
70		**8-98249989-1**	RADIATOR ASM	Radiator
71		**8-98291696-1**	RADIATOR ASM	Radiator
72		**8-97249541-1**	RADIATOR RUBBER BUSHING	Radiator Bush
73		**8-97942268-1**	RADIATOR COOLANT CAP	Radiator Cap
74		**8-97912540-0**	VALVE: RELIEF, OIL	Relief Valve
75		**8-98369974-0**	RUBBER: ENG FOOT, F	Rubber Cushion
76		**8-98369975-1**	RUBBER: ENG FOOT, F	Rubber Cushion
77		**8-97046705-3**	SEAL: OIL, RR COVER	Seal Cover
78		**8-98037543-0**	COVER SEAL, NOZZLE	Seal Cover


NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
79		**8-97120307-0**	SEAL: VLV GUIDE	Seal Valve
80		**8-97328647-0**	SEAL: VLV GUIDE	Seal Valve
81		**8-98258885-0**	TENSIONER: CHAIN	Tensioner Assy
82		**8-98276119-1**	TENSIONER: DRIVE B	Tensioner Assy
83		**8-97354055-1**	WASHER: THRUST, CR	Thrust Washer
84		**8-97944199-0**	WASHER: THRUST,CR	Thrust Washer
85		**8-97309675-1**	VALVE: INL	Valve
86		**8-97309677-1**	VALVE: EXH	Valve
87		**8-97940024-0**	VALVE: INL	Valve
88		**8-97940025-0**	VALVE, EXH	Valve

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
89		**8-98013911-1**	VALVE: EGR	Valve
90		**5-11721016-0**	GUIDE, VLV	Valve Guide
91		**8-98132029-0**	PIPE: WATER	Water Pipe
92		**8-98373699-0**	PIPE: WATER OUTLET	Water Pipe
93		**8-97312147-4**	PUMP ASSEMBLY: WATER	Water Pump
94		**7-55243644-0**	PUMP ASM: WATER	Water Pump Assy
BODY PARTS				
95		**8-98102202-3**	BOLT RUBBER	Bolt
96		**8-98178536-0**	BOLT: RUBBER	Bolt
97		**8-98074256-4**	RETAINER: FRT BUMP	Bumper Retainer

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
98		**8-98074257-4**	RETAINER: FRONT BUMPER	Bumper Retainer
99		**8-98074258-5**	RETAINER: FRT BUMP	Bumper Retainer
100		**8-98074259-5**	RETAINER: FRONT BUMP	Bumper Retainer
101		**8-98248819-1**	RETAINER: FRT BUMP	Bumper Retainer
102		**8-98248820-1**	RETAINER: FRT BUMP	Bumper Retainer
103		**8-98248821-1**	RETAINER: FRT BUMP	Bumper Retainer
104		**8-98248822-1**	RETAINER: FRT BUMPER	Bumper Retainer
105		**8-98395187-2**	RETAINER: FRT BUMPER	Bumper Retainer
106		**8-98395188-2**	RETAINER: FRT BUMPER	Bumper Retainer
107		**8-98103030-5**	ARM: CHECK, FRONT DOOR	Check Assy


NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
108		**8-98103031-3**	ARM: CHECK, RR DOOR	Check Strap Stopper Hinge
109		**8-97941410-0**	HINGE: DOOR FRT	Door Hinge
110		**8-97941411-0**	HINGE: DOOR FRT	Door Hinge
111		**8-97941412-0**	HINGE: DOOR FRT	Door Hinge
112		**8-97910926-0**	LOCK: DOOR,FRT DOOR	Door Lock
113		**8-97910927-0**	LOCK: DOOR, FRT DOOR	Door Lock
114		**8-97500668-0**	COVER: CHECK HOLE	Dust Boot/Cover
115		**8-98007122-4**	INSULATION: ENGINE HOOD	Engine Hood
116		**8-97549747-2**	FENDER: FRONT	Fender Panel
117		**8-97549748-2**	FENDER: FRT	Fender Panel

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
118		**8-98103206-1**	FENDER: FRONT	Fender Panel
119		**8-98103208-1**	FENDER: FRONT	Fender Panel
120		**8-97550939-2**	BUMPER ASM: FRT	Front Bumper Cover
121		**8-98343329-0**	BUMPER ASM: FRT	Front Bumper Cover
122		**8-98343330-0**	BUMPER ASM: FRT	Front Bumper Cover
123		**8-98343331-1**	BUMPER ASM: FRT	Front Bumper Cover
124		**8-98395124-5**	BUMPER ASM: FRT	Front Bumper Cover
125		**8-97547106-1**	BAR: FRT BUMPER	Front Bumper Support
126		**8-98087390-1**	SUPPORT: FRONT BUMPER	Front Bumper Support
127		**8-98165341-0**	STAY: ENG HOOD, FRT	Front Cover Pillar

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
128		**8-98386268-1**	HINGE: ENGINE HOOD	Hood Hinge
129		**8-98386276-1**	HINGE: ENGINE HOOD	Hood Hinge
130		**8-98340013-0**	HUB CAP, FRT AXLE	Hub Cap
131		**8-98050279-0**	LATCH, END GATE	Latch End Gate
132		**8-97236072-1**	LOCK: DOOR, FRONT DOOR	Lock Assy
133		**8-97239342-0**	MOLDING: WINDSHIELD	Moulding Windshield
134		**8-98051336-0**	RUBBER, CUSHION	Mounting Cushion
135		**8-98193346-0**	RUBBER, CUSHION	Mounting Cushion
136		**8-98193626-0**	RUBBER, CUSHION	Mounting Cushion
137		**8-98103202-0**	PANEL: DEFLECTOR	Panel Deflector

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
138		**8-97235330-3**	PANEL: ROOF	Roof Panel
139		**8-98103950-3**	PANEL: ROOF	Roof Panel
140		**8-97367286-0**	RUBBER: CUSHION, CA	Rubber Cushion
141		**8-98051329-0**	RUBBER CUSHION,BO	Rubber Cushion
142		**8-98193344-0**	RUBBER: CUSHION, EN	Rubber Cushion
143		**8-98140693-0**	SEAL: BACKLIGHT GL	Seal
144		**8-98160817-8**	PANEL: SIDE OUTER	Side Panel
145		**8-98160830-8**	PANEL: SIDE OUTER	Side Panel
146		**8-97215052-0**	RUBBER: BUMPER, STR	Spring Bumper Front
147		**8-98004221-0**	WEATHERSTRIP: FRT	Weatherstrip

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
148		**8-97234964-4**	PANEL: WHEEL HOUSE	Wheel House Panel
149		**8-98074560-0**	PANEL: WHEEL HOUSE	Wheel House Panel
150		**8-98103211-3**	PANEL: WHEEL HOUSE	Wheel House Panel
151		**8-98193272-3**	PANEL: WHEEL HOUSE	Wheel House Panel
152		**8-98009811-2**	REGULATOR ASM: DOOR	Window Regulator
153		**8-98093551-1**	FRONT DOOR WINDOW REGULATOR	Window Regulator
154		**8-98093552-1**	REGULATOR: WINDOW,	Window Regulator
155		**8-98111488-1**	REGULATOR: WINDOW,	Window Regulator
156		**8-98111489-1**	REGULATOR: WINDOW,	Window Regulator

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
BRAKE / DIFFERENTIAL				
157		**8-97216797-2**	BEARING: RR AXLE	Bearing
158		**8-97360677-2**	ROTOR: DISC BRAKE, FR	Brake Disc
159		**8-97948806-1**	ROTOR: DISC BRK, FR	Brake Disc
160		**8-98079104-0**	PAD KIT: CALIPER,D	Caliper Pad Kit
161		**8-97360505-0**	DRUM: BRAKE, RR	Drum Brake
162		**8-98030385-0**	DRUM: BRAKE, RR	Drum Brake
163		**8-97355870-0**	CYLINDER ASM: BRK	Master Cylinder Brake
164		**8-98006941-0**	CYLINDER ASM: BRK	Master Cylinder Brake
165		**8-98320668-0**	CYLINDER ASM, BRK	Master Cylinder Brake

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
166		**8-98320670-0**	CYLINDER ASM: BRK	Master Cylinder Brake
167		**8-98320671-0**	CYLINDER ASM: BRAKE	Master Cylinder Brake
168		**8-98036593-0**	SEAL OIL, FRT HUB	Oil Seal
169		**8-98392204-0**	SEAL: OIL, KNUCKLE	Oil Seal
170		**8-98007008-1**	CABLE, PARKING BRK	Parking Brake Cable
171		**8-98007010-1**	CABLE, PARKING BRK	Parking Brake Cable
172		**8-97319300-0**	CYLINDER: WHEEL, RR	Wheel Brake Cylinder
173		**8-97944831-1**	PIN: WHEEL, RR AXLE	Wheel Pin
SUSPENSION PARTS				
174		**8-98005826-0**	JOINT ASM, BALL UP	Ball Joint

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
175		**8-98005874-0**	JOINT ASM, BALL LW	Ball Joint
176		**8-98055745-0**	BOOT KIT: STRG HSG	Boot Kit
177		**8-97247083-0**	BUSHING, RUBBER ST	Bush
178		**8-97332642-0**	BUSHING: LEAF SPR	Bush
179		**8-97302810-0**	SHOCK ABSORBER BUSH	Bush Suspension
180		**8-97364176-0**	BUSHING: LWR LINK	Bush Suspension
181		**8-97944575-0**	LINK ASM: STABILIZER	Front Stabilizer Link
182		**8-97648441-2**	RUBBER, CUSHION	Mounting Cushion
183		**0-91110522-0**	NUT, LWR LINK TO	Nut
184		**8-97349476-0**	CAP: OIL TANK, P/S	Oil Tank Cap

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
185		**8-97234350-1**	TANK ASM: OIL, P/S	Power Steering Oil Tank
186		**8-98055744-0**	REPAIR KIR: STRG U	Repair Kit Strg
187		**8-98164967-0**	REPAIR KIT, STRG U	Repair Kit Strg
188		**8-98055746-0**	ROD END ASM: OUTER	Rod End Asm: Outer
189		**8-97264184-0**	BUSHING: RUBBER	Rubber Bushing
190		**8-97357492-0**	BUSHING: SHACKLE, REAR	Rubber Bushing
191		**8-97364173-0**	BUSHING: UPR LINK	Rubber Bushing
192		**8-97947039-0**	BUSHING: RUBBER, ST	Rubber Bushing
193		**8-98005829-0**	BRACKET, FRT S/ABS	Shock Absorber Bracket Front

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
ELECTRICAL COMPONENTS				
194		**8-98393361-4**	LAMP ASM: FRT TURN	Fog Lamp
195		**8-98393362-4**	LAMP ASM: FRT TURN	Fog Lamp
196		**8-98395156-0**	BEZEL: FOG LAMP	Fog Lamp Bezel
197		**8-98395157-0**	BEZEL: FOG LAMP	Fog Lamp Bezel
198		**8-98395159-0**	BEZEL: FOG LAMP	Fog Lamp Bezel
199		**8-98395160-0**	BEZEL: FOG LAMP	Fog Lamp Bezel
200		**8-98186199-2**	HEADLAMP UNIT	Headlight
201		**8-98186200-2**	HEADLAMP UNIT	Headlight
202		**8-98186215-0**	HEADLAMP UNIT	Headlight

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
203		**8-98276305-0**	HEADLAMP UNIT	Headlight
204		**8-98276306-0**	HEADLAMP UNIT	Headlight
205		**8-97237046-0**	HORN: HIGH NOTE	Horn
206		**8-97237047-0**	HORN: LOW NOTE	Horn
207		**8-97508861-5**	LAMP ASM: HEAD	Lamp
208		**8-97508862-5**	LAMP ASM: HEAD	Lamp
209		**8-98125402-3**	LAMP ASM: RR COMB	Lamp
210		**8-98186216-0**	HEADLAMP UNIT	Lamp
211		**8-98328799-4**	LAMP ASM, RR COMB	Lamp
212		**8-98328806-4**	LAMP ASM, RR COMB	Lamp

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
213		**7-55278821-0**	RESISTOR: BLOWER	Resister Blower
214		**8-97387989-1**	SENSOR: SPD, FRT WH	Sensor
215		**8-97387990-1**	SENSOR: SPD, FRT WH	Sensor
216		**8-98292433-1**	SENSOR: SPD,FRT WH	Sensor
217		**8-98371294-1**	SENSOR: SPD,FRT WH	Sensor
218		**8-98140486-0**	SWITCH: STOP LAMP	Stop Lamp Switch
219		**8-97375606-2**	LAMP ASM: RR COMB	Tail Lights
220		**8-97375607-2**	LAMP ASM: RR COMB	Tail Lights
221		**8-98125403-3**	LAMP ASM: RR COMB	Tail Lights

NO.	IMAGE	PART NUMBER	DESCRIPTION	PART TYPE
FILTERS				
222		**1-14215078-0**	FILTER ACL, INNER	Air Filter
223		**8-98140266-0**	FILTER: ACL	Air Filter
224		**8-98321413-0**	FILTER: ACL	Air Filter
225		**8-97288947-0**	CARTRIDGE KIT, FUEL	Cartridge Kit
226		**8-97916993-2**	ELEMENT KIT: FUEL FILTER	Fuel Filter
227		**5-87615000-0**	ELEMENT, OIL FILTER	Oil Filter
228		**8-97309927-0**	ELEMENT, OIL FILTER	Oil Filter
229		**8-98270524-0**	ELEMENT: OIL FILTER	Oil Filter